Table des matières

remplacement power 3

remplacement power

```
BWR-01-sc0:sms-svc:3> showenvironment -p powers

POWER           UNIT     AC0      AC1      DC0      DC1      FAN0     FAN1
-----           ----     ---      ---      ---      ---      ----     ----
A211 at PS0     OK       OK       OK       ON       ON       OK       OK
A211 at PS1     OK       OK       OK       ON       ON       OK       OK
A211 at PS2     FAIL     FAIL     FAIL     OFF      OFF      OK       OK
A211 at PS3     OK       FAIL     OK       ON       ON       OK       OK
A211 at PS4     OK       FAIL     OK       ON       ON       OK       OK
A211 at PS5     OK       FAIL     OK       ON       ON       OK       OK
```

- In case of reset of a domain 25k: change post level to 7 in order to avoid 2h of post check

```
cd $SMSETC
profile
```

From:
https://unix-bck.ndlp.info/ - **Where there is a shell, there is a way**

Permanent link:
https://unix-bck.ndlp.info/doku.php/informatique:nix:solaris:solaris_25k

Last update: **2015/03/31 07:57**