Table des matières

M9000 3

M9000

```
showboards -a
showfru
showdomainstatus
showhardconf
```

```
showlogs -d 2 error/console
```

```
SCF> showboards -d 10
XSB  DID(LSB) Assignment  Pwr  Conn Conf Test    Fault
---- -------- ---------- ---- ---- ---- ------- --------
00-3 10(00)   Assigned    y    y    y    Passed  Normal
06-2 10(01)   Assigned    y    y    y    Passed  Normal
XSCF>
XSCF>
XSCF>
XSCF> showdcl -d 10
DID   LSB   XSB   Status
10                Running
      00    00-3
      01    06-2

XSCF> showdcl -d 23
DID   LSB   XSB   Status
23                Powered Off
      01    04-2
      02    15-0
      03    03-3
      04    08-2
      05    08-3
```

```
xscf> deleteboard -c unassign 03-3 08-3
xscf> setdcl -d 23 -r 03 05
XSCF> setdcl -d 10 -a 2=03-3
XSCF> setdcl -d 10 -a 3=08-3

XSCF> showboards -c sp -d 10

showdcl -v -d 10
addboard -c configure -d 10 03-3
addboard -c configure -d 10 08-3

====================================
====================================
M9K_NR02  Add :
CPU0 de PSB3 et CPU1 de PSB13

xscf poweroff -d 23
xscf> deleteboard -c unassign 03-0 13-1
xscf> setdcl -d 23 -r 01 04
XSCF> setdcl -d 8 -a 4=03-0
XSCF> setdcl -d 8 -a 5=13-1

XSCF> showboards -c sp -d 8

showdcl -v -d 8
addboard -c configure -d 8 03-0
addboard -c configure -d 8 13-1
```

From:
https://unix-bck.ndlp.info/ - **Where there is a shell, there is a way**

Permanent link:
https://unix-bck.ndlp.info/doku.php/informatique:nix:solaris:solaris_mxxxx

Last update: **2015/04/16 15:26**